

Install 1/2-in Poly Fittings With Ease



1) Expose O-Ring

A close-up photograph of a hand holding a black plastic fitting. The top cap is being lifted, revealing a white O-ring seated inside the fitting's bore.



2) Push Poly over O-Ring

A close-up photograph showing a hand pushing a black poly pipe into the fitting. A white arrow points from the pipe towards the fitting's opening.



3) Tighten Collar over Poly

A close-up photograph showing a hand rotating the top collar of the fitting. A white arrow indicates the direction of rotation.